





LATIKA







- | | |
|---|-------------------------------------|
| (D) Montageanleitung | (GB) Assembly instructions |
| (FR) Notice de montage | (IT) Istruzioni di montaggio |
| (NL) Handleiding voor de montage | (PL) Instrukcja montażu |
| (CZ) Montážní návod | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (RO) Instrucțiuni de montaj |
| (TR) Montaj talimatı | (RU) ИНСТРУКЦИЯ ПО МОНТАЖУ |




1- 1,5

1




2



FD L=250
x2




3




- | | |
|----------------|----------------|
| A 8x35
x4 | B
x2 |
| N 3,5x16
x4 | FD L=250
x2 |




4



- | | |
|---------------|----------|
| NH 3x12
x1 | ZE
x1 |
| C 15x12
x2 | X
x10 |
| A 8x35
x4 | B
x2 |
| Y 7x50
x2 | SB
x1 |



5



6

- | |
|----------------|
| N 3,5x16
x4 |
| FD L=250
x2 |

